



B O I S

B O I S



Assiette coupe • Coupe plate

D. 29,5 cm H. 3,2 cm / D. 11.6" H. 1.3" 5106/21406
 D. 27 cm H. 3 cm / D. 10.6" H. 1.2" 5106/21259
 D. 14 cm H. 1,9 cm / D. 5.5" H. 0.7" 5106/21447



Planche ronde • Round platter

D. 30 cm / D. 12"
 5106/22262



Planche restangulaire GM
 Large rectangular platter

35 x 25 cm / 14 x 10"
 5106/22260



Planche restangulaire PM
 Small rectangular platter

27 x 19 cm / 10.6 x 7.5"
 5106/22261



Tasse et soucoupe café
 Coffee cup and saucer 5106/8568

Tasse 6 cl D. 5,5 cm H. 7 cm / Cup 2 oz D. 4.7" H. 2.7"
 5106/8553
 Soucoupe D. 12 cm / Saucer D. 4.7"
 5106/8552

Tasse et soucoupe thé
 Tea cup and saucer 5106/20881

Tasse 17 cl D. 8 cm / Cup 5.7 oz D. 3.1" 5106/8366
 Soucoupe D. 14,5 cm / Saucer D. 5.7" 5106/143/2



Assiette coupe • Coupe plate

D. 29,5 cm H. 3,2 cm / D. 11.6" H. 1.3" 5107/21406
 D. 27 cm H. 3 cm / D. 10.6" H. 1.2" 5107/21259
 D. 14 cm H. 1,9 cm / D. 5.5" H. 0.7" 5107/21447



Tasse et soucoupe café
 Coffee cup and saucer 5107/8568

Tasse 6 cl D. 5,5 cm H. 7 cm / Cup 2 oz D. 4.7" H. 2.7" 5107/8553
 Soucoupe D. 12 cm / Saucer D. 4.7" 5107/8552

Tasse et soucoupe thé
 Tea cup and saucer 5107/20881

Tasse 17 cl D. 8 cm / Cup 5.7 oz D. 3.1" 5107/8366
 Soucoupe D. 14,5 cm / Saucer D. 5.7" 5107/143/2

