



ORIGINE
COULEUR

ORIGINE
BLEU / BLUE



Assiette coupe • *Plate*

D. 31 cm / D. 12" 1699/2134
D. 27 cm / D. 10.6" 1699/21259
D. 21 cm / D. 8.5" 1699/21260
D. 16 cm / D. 6.5" 1699/3
D. 14 cm / D. 5.5" 1699/21447



Assiette creuse calotte • *Coupe soup*

D. 19 cm / D. 7.5" 1699/26



Assiette creuse à pâtes • *Pasta plate*

D. 24 cm / D. 9.5"
1699/3402



Compotier • *Open vegetable dish*

D. 25 cm / D. 9.8"
1699/53



Assiette à Tapas • *Tapas*

D. 25 cm / D. 9.8" 1699/20972



Assiette ovale • *Oval plate*

D. 33 cm / D. 13" 1699/21073



Tasse à café • *Coffee cup*

7 cl D. 7 cm H. 4,5 cm / 2.5 oz D. 2.7" H. 1.8" 0579/163

Soucoupe • *Saucer*

D. 11,5 cm / D. 4.5" 1699/135



Tasse à thé • *Tea cup*

20 cl D. 10 cm H. 6 cm / 7 oz D. 3.9" H. 2.3" 0579/175

Soucoupe • *Saucer*

D. 16,5 cm / D. 6.5" 1699/143

ORIGINE

CHOCOLAT / BROWN



Assiette coupe • *Plate*

D. 31 cm / D. 12" 1697/2134
 D. 27 cm / D. 10.6" 1697/21259
 D. 21 cm / D. 8.5" 1697/21260
 D. 16 cm / D. 6.5" 1697/3
 D. 14 cm / D. 5.5" 1697/21447



Assiette creuse calotte • *Coupe soup*

D. 19 cm / D. 7.5" 1697/26



Assiette creuse à pâtes • *Pasta plate*

D. 24 cm / D. 9.5"
 1697/3402



Compotier • *Open vegetable dish*

D. 25 cm / D. 9.8"
 1697/53



Assiette à Tapas • *Tapas*

D. 25 cm / D. 9.8" 1697/20972



Assiette ovale • *Oval plate*

D. 33 cm / D. 13" 1697/21073



Tasse à café • *Coffee cup*

7 cl D. 7 cm H. 4,5 cm / 2.5 oz D. 2.7" H. 1.8" 0579/163

Soucoupe • *Saucer*

D. 11,5 cm / D. 4.5" 1697/135



Tasse à thé • *Tea cup*

20 cl D. 10 cm H. 6 cm / 7 oz D. 3.9" H. 2.3" 0579/175

Soucoupe • *Saucer*

D. 16,5 cm / D. 6.5" 1697/143

ORIGINE
GRIS / GREY



Assiette coupe • *Plate*

D. 31 cm / D. 12" 1700/2134
D. 27 cm / D. 10.6" 1700/21259
D. 21 cm / D. 8.5" 1700/21260
D. 16 cm / D. 6.5" 1700/3
D. 14 cm / D. 5.5" 1700/21447



Assiette creuse calotte • *Coupe soup*

D. 19 cm / D. 7.5" 1700/26



Assiette creuse à pâtes • *Pasta plate*

D. 24 cm / D. 9.5"
1700/3402



Compotier • *Open vegetable dish*

D. 25 cm / D. 9.8"
1700/53



Assiette à Tapas • *Tapas*

D. 25 cm / D. 9.8" 1700/20972



Assiette ovale • *Oval plate*

D. 33 cm / D. 13" 1700/21073



Tasse à café • *Coffee cup*

7 cl D. 7 cm H. 4,5 cm / 2.5 oz D. 2.7" H. 1.8" 0579/163

Soucoupe • *Saucer*

D. 11,5 cm / D. 4.5" 1700/135



Tasse à thé • *Tea cup*

20 cl D. 10 cm H. 6 cm / 7 oz D. 3.9" H. 2.3" 0579/175

Soucoupe • *Saucer*

D. 16,5 cm / D. 6.5" 1700/143

ORIGINE
ROSE / PINK



Assiette coupe • *Plate*

D. 31 cm / D. 12" 1701/2134
D. 27 cm / D. 10.6" 1701/21259
D. 21 cm / D. 8.5" 1701/21260
D. 16 cm / D. 6.5" 1701/3
D. 14 cm / D. 5.5" 1701/21447



Assiette creuse calotte • *Coupe soup*

D. 19 cm / D. 7.5" 1701/26



Assiette creuse à pâtes • *Pasta plate*

D. 24 cm / D. 9.5"
1701/3402



Comptier • *Open vegetable dish*

D. 25 cm / D. 9.8"
1701/53



Assiette à Tapas • *Tapas*

D. 25 cm / D. 9.8" 1701/20972



Assiette ovale • *Oval plate*

D. 33 cm / D. 13" 1701/21073



Tasse à café • *Coffee cup*

7 cl D. 7 cm H. 4,5 cm / 2.5 oz D. 2.7" H. 1.8" 0579/163

Soucoupe • *Saucer*

D. 11,5 cm / D. 4.5" 1701/135



Tasse à thé • *Tea cup*

20 cl D. 10 cm H. 6 cm / 7 oz D. 3.9" H. 2.3" 0579/175

Soucoupe • *Saucer*

D. 16,5 cm / D. 6.5" 1701/143

ORIGINE
VERT / GREEN



Assiette coupe • *Plate*

D. 31 cm / D. 12" 1698/2134
D. 27 cm / D. 10.6" 1698/21259
D. 21 cm / D. 8.5" 1698/21260
D. 16 cm / D. 6.5" 1698/3
D. 14 cm / D. 5.5" 1698/21447



Assiette creuse calotte • *Coupe soup*

D. 19 cm / D. 7.5" 1698/26



Assiette creuse à pâtes • *Pasta plate*

D. 24 cm / D. 9.5"
1698/3402



Comptier • *Open vegetable dish*

D. 25 cm / D. 9.8"
1698/53



Assiette à Tapas • *Tapas*

D. 25 cm / D. 9.8" 1698/20972



Assiette ovale • *Oval plate*

D. 33 cm / D. 13" 1698/21073



Tasse à café • *Coffee cup*

7 cl D. 7 cm H. 4,5 cm / 2.5 oz D. 2.7" H. 1.8" 0579/163

Soucoupe • *Saucer*

D. 11,5 cm / D. 4.5" 1698/135



Tasse à thé • *Tea cup*

20 cl D. 10 cm H. 6 cm / 7 oz D. 3.9" H. 2.3" 0579/175

Soucoupe • *Saucer*

D. 16,5 cm / D. 6.5" 1698/143